

# RWK-381H

line sectionalizing load break switch controller

Improve power supply reliability

Optimize the operation of the power system

Save maintenance costs

Flexible application scenarios



Comply with IEC / CEI /GB/JB/DL standards

Provided customized manufacture

Whole solutions for design, assembly, test...

Accountable solution for safety and reliability

Wide range offering, easy business and convenient installation

## Foreword

### **Please read this chapter carefully before using this product!**

This chapter introduces the safety precautions before using this product. Please make sure the content of this chapter is fully read and understood before installation and usage. Our company will not undertake any responsibilities for any damage or injury caused by improper operations because of ignoring relevant warning in this operation instruction.

Before operating this device, relevant professional personnel shall read this instruction carefully and well understand the content.

Operation instructions and warnings:

The following standard definitions will be adopted in this operation instruction.

**Danger!** Ignoring of safety precautions may cause personal death, serious personal injury or serious equipment damage.

**Warning!** Ignoring of safety precautions may cause personal death, serious personal injury or serious equipment damage.

**Caution!** Ignoring of safety precautions may cause a slight personal injury or equipment damage, especially the damage of device or the equipment protected by the device.

- **Danger!**

When the primary system is live working, secondary open circuit for the current transformer connected to the device is absolutely forbidden, and the open of this circuit may cause extremely dangerous high voltage.

- **Warning!**

Some parts of the device may have high voltage when the electrical device is running. Improper operation may cause serious personal injury or equipment damage.

Only qualified professional personnel are allowed to operate the device or work nearby the device. The operators professional shall well understand the precautions, working flows and safety regulations mentioned in this instruction.

- **Caution!**

Grounding terminals of the device shall be firmly grounded.

The device is only permitted to run in atmospheric environment that specified in the technical specifications, and abnormal vibrations shall be avoided in its running environment.

When connect the AC voltage current circuit or power circuit, please make sure they conform to the rated parameters of the device.

When the output terminals of the device are connected to external circuit, please check carefully the voltage of external power to prevent overheating of the circuit.

Carefully check the cable connected to the device, preventing applying too much external force on it.

- **Note!**

Every care has been taken in preparation of this manual. However, please note that not all the details or variations in the equipment or process being described can be covered. Neither is it expected to address all contingencies associated with the installation and operation of this equipment. If you need more information, please contact the manufacturer.

The fixed value in the picture is only for demonstration, not for actual configuration.

# Contents

<b>CHAPTER 1: OVERVIEW .....</b>	<b>5</b>
1.1 Description .....	5
1.2 Protection .....	5
1.4 Supervision .....	5
1.5 Control .....	5
1.6 Features .....	6
1.7 Monitoring Functions .....	6
1.8 Hardware .....	7
1.9 Data Storage and Communication .....	7
<b>CHAPTER 2: TECHNICAL PERFORMANCE INDEX .....</b>	<b>8</b>
2.1 Inputs and Outputs .....	8
2.2 Unit Design .....	10
2.3 Serial Interface .....	10
2.4 Data Storage .....	10
2.5 Mechanical Tests .....	10
2.6 Electrical Tests .....	11
2.7 Climatic Tests .....	13
<b>CHAPTER 3: PROTECTION FUNCTIONALITY .....</b>	<b>14</b>
3.1 Function Description .....	14
3.2 Inverse time current protection .....	22
3.3 Constant Value Parameters .....	43
3.4 Data Storage .....	47
<b>CHAPTER 4: USER INTERFACE .....</b>	<b>48</b>
4.1 Status and Trip Target LEDs .....	49
4.2 Pushbuttons .....	49
4.3 Operator Controls .....	50

4.4 Default Display .....	52
4.5 The Main Menu .....	52
4.6 Submenu .....	53
4.7 Entering the password interface .....	55
4.8 Relay setting .....	56
4.9 Save parameter .....	65
4.10 Parameter set .....	65
4.11 Communication .....	67
4.12 Calibration .....	69
4.13 Clear .....	69
4.14 Auto switch group .....	69
4.15 View relay and setting .....	69
4.16 View report .....	70
4.17 View input signal .....	70
<b>CHAPTER 5: PERIPHERAL ACCESSORIES .....</b>	<b>71</b>
5.1 RF remote controller .....	71
5.2 Features and the use of external sockets and switches .....	71
5.3 The main secondary component parts .....	72
5.4 Capacitor (Used by permanent recloser) .....	72
5.5 Battery .....	72
<b>CHAPTER 6: INSTALLATION AND MAINTENANCE .....</b>	<b>73</b>
6.1 Installation .....	73
6.2 Maintenance .....	73
6.3 Parts Attached with the Device .....	73
<b>CHAPTER 7: DECOMMISSION AND DISPOSAL .....</b>	<b>74</b>
7.1 Decommission .....	74
7.2 Disposal .....	74

## Chapter 1: Overview

### 1.1 Description

RWK-381 line sectionalizing load break switch controller is a kind of switch which must cooperate with superior switch. It can't cut off the fault current, it only trip when the line is low-voltage or no-current.

RWK-381 line sectionalizing load break switch controller adopts IT operation mode.

When a fault happened, the controller will record the fault times. If the times come to the setting value, the controller will trip after the line is low-voltage or no-current.

The controlling box is made of stainless steel, the surface is dealt with painting, anticorrosion, can be used in outdoor environments.

It has charging circuit: It could take AC220V charging power supply from outside. If there is no power supply outside, it also could achieve opening/closing operation and all controller functions with battery. Besides that, it is set with anti-over discharge circuit for protecting the battery when there is no electricity of the power supply outside for a long time.

### 1.2 Protection

Section function (Section)

**50** Instantaneous/Definite-Time Overcurrent (P.OC)

**51** Phase Time-Overcurrent (P.OC2/P.OC3)

Over Load (Overload)

**50N** Residual Ground Instantaneous/Definite-Time Overcurrent (G.OC)

**51N** Residual Ground Time-Overcurrent (G.OC2/G.OC3)

**50SEF** Sensitive Earth Fault (SEF)

**51c** Cold Load (Cold load)

TRSOTF Switch-Onto-Fault (SOTF)

**59** Over Voltage (L.Over volt)

**27** Under Voltage (L.Under volt)

### 1.4 Supervision

74T/CCS      Trip & Close Circuit Supervision

60VTS      VT Supervision

### 1.5 Control

86      Lockout

CB Control

## **1.6 Features**

Password Protection – 2 levels.

50Hz/60Hz systems and two phase/three phase wiring method are available, so that the use scope of device is extended.

Protection configuration is complete, and all protection functions can be switched on and off flexibly.

9-way intellectual switching value input.

Large capacity flash memory can record at least 100 times of historical events, and no data will loss even the power is off.

Circuits operating loop can be used both the direct or alternating current, self-adaptation open/close brake function, which can co-work with various of breakers, and the operation is simple and reliable.

The device has complete self-inspection function to in-service monitor the working conditions of various parts of the device, ensuring the reliability of the device.

## **1.7 Monitoring Functions**

Primary/Secondary Phases and Earth Currents

Direction

Primary/Secondary Line and Phase Voltages

Apparent Power and Power Factor

Real and Reactive Power

Positive Phase Sequence Voltage

Negative Phase Sequence Voltage & Current

Zero Phase Sequence Voltage

Earth Current With 3RD Harmonics

Frequency

Binary Input/Output status

Trip circuit healthy/failure

Time and date

Event records

Counters

Wear

## **1.8 Hardware**

4 CT

7 VT

1 Battery

9 Binary Inputs

4 Binary Outputs

## **1.9 Data Storage and Communication**

RS485/USB or RS485/RS232 port and Ethernet/RJ45

Protocols –IEC60870-5-101, IEC60870-5-104, DNP3.0 or Modbus RTU

Event Records

Fault Records

Measurands

Commands

Time Synchronism

Viewing and Changing Settings



## Chapter 2: Technical Performance Index

### 2.1 Inputs and Outputs

#### Phase Current Inputs

Quantity	3
Rated Current In	5A
Measuring Range	20 x In
Instrumentation $\geq 0.1 \times \text{In}$	$\pm 1\% \text{ In}$
Frequency	50/60Hz
Thermal Withstand:	
Continuous	2 x In
10 Second	10 x In
1 Second	40 x In
Burden @ In	$\leq 0.2 \text{VA}$ (5A Phase element)

#### Sensitive Earth Current Inputs

Quantity	1
Rated Current In	5A
Measuring Range	2 x In
Instrumentation $\geq 0.1 \times \text{In}$	$\pm 1\% \text{ In}$
Frequency	50/60Hz
Thermal Withstand:	
Continuous	2 x In
10 Second	10 x In
1 Second	40 x In
Burden @ In	$\leq 0.02 \text{VA}$ (1A Earth element)

**Voltage Inputs**

Quantity	1 PT voltage
Nominal	40...120 Vrms
Operating Range	0...200 Vrms
Instrumentation $\geq 0.8 \times V_n$	$\pm 1\% V_n$
Burden @ 110V	0.06 VA
Overvoltage Withstand	240 Vrms

**Voltage sensor Inputs**

Quantity	6 x Voltage sensor
Nominal	0...60 Vrms

**Auxiliary Supply**

DC Voltage	220V Range 110 to 265V
AC Voltage	220 V AC 50/60Hz Range 165 to 265Vrms AC 50/60Hz $\pm 5\%$
Power consumption	$\leq 100W/300W$

**Binary Inputs**

Number	9
Operating Voltage	24V DC
Maximum dc current for operation	2mA

## Binary Outputs

Number	2
Operating Voltage	220V DC
Operating Mode	User selectable - Self or Hand/Electrical Reset or pulsed
Operating Time from Energizing Binary Input	<20ms

## 2.2 Unit Design

Indication	16 Character 4 line Display 10 LED's
User Interface	12 Navigation Keys
Weight	32kg

## 2.3 Serial Interface

Communication Port	RS485 or USB
Protocols	IEC60870-5-101 IEC60870-5-104 DNP3.0 MODBUS RTU

## 2.4 Data Storage

Events	100 times
--------	-----------

## 2.5 Mechanical Tests

### Vibration (Sinusoidal) --- IEC 60255-21-1 Class I

Type	Level	Variation
Vibration response	0.5gn	≤5%
Vibration withstand	1.0gn	≤5%

**Shock and Bump --- IEC 60255-21-2 Class I**

Type	Level	Variation
Shock response	0.5gn, 11ms	≤5%
Shock withstand	15gn, 11ms	≤5%
Bump test	10gn,16ms	≤5%

**Shock and Bump --- IEC 60255-21- 3 Class I**

Type	Level	Variation
Seismic response	X-plane-3.5mm Displacement below crossover freq (8-9Hz) 1gn and above	≤5%
	Y-plane-1.5mm Displacement below crossover freq (8-9Hz) 0.5gn above	

**Mechanical Classification**

Durability	>106 operations
------------	-----------------

**2.6 Electrical Tests****Insulation --- IEC 60255-5**

Type	Level
Between any terminal and earth	2.0 kV AC RMS for 1 min
Between independent circuits	2.0 kV AC RMS for 1 min
Across normally open contacts	kV AC RMS for 1 min

**High Frequency Disturbance --- IEC 60255-22-1 Class III**

Type	Level	Variation
Common (longitudinal) mode	2.5 kV	≤5%
Series (transverse) mode	1.0 kV	≤5%

**High Frequency Disturbance --- IEC 60255-22-2 Class IV**

Type	Level	Variation
Contact discharge	8.0 kV	≤5%

**Fast Transients --- IEC 60255-22-4 Class A (2002)**

Type	Level	Variation
5/50 ns 2.5 kHz repetitive	4 kV	≤5%

**Surge Immunity --- IEC 60255-22-5**

Type	Level	Variation
Analog Inputs: Line to Earth	4.0 kV	≤10%
Case, Aux Power & I/O: Line to Earth	2.0 kV	≤10%
RS485 Comms port: Line to Earth	1.0 kV	No Data Loss
Analog Inputs: Line to Line	1.0 kV	≤10%
Case, Aux Power & I/O: Line to Line	1.0 kV*	≤10%

\* Note 45ms DTL pick-up delay applied to binary inputs

**Conducted Radio Frequency Interference --- IEC 60255-22-6**

Type	Level	Variation
0.15 to 80 MHz	10 V	≤5%

**Radiated Radio Frequency --- IEC 60255-25**

Type	Limits at 10 m, Quasi-peak
30 to 230 MHz	40 dB(μV)
230 to 10000 MHz	47 dB(μV)

**Conducted Radio Frequency**

Type	Limits	
	Quasi-peak	Average
0.15 to 0.5 MHz	79 dB(μV)	66 dB(μV)
0.5 to 30 MHz	73 dB(μV)	60 dB(μV)

**Radiated Immunity --- IEC 60255-22-3 Class III**

Type	Level
80 MHz to 1000 MHz Sweep	10 V/m
1.4GHz to 2.7GHz Sweep	10 V/m
80,160,380,450,900,1850,2150 MHz Spot	10 V/m

**2.7 Climatic Tests****Temperature --- IEC 60068-2-1/2**

Operating Range	-10°C to +55°
Storage range	-25°C to +70°

**Humidity --- IEC 60068-2-78**

Operational test	56 days at 40°C and 93% relative humidity
------------------	--

## Chapter 3: Protection Functionality


### 3.1 Function Description

#### Section function

The section function must cooperate with superior switch. It can't cut off the fault current, it only trip when the line is low-voltage or no-current.

When a failure occurs on the line, the current exceeds the protection value which you set, superior switch cut off the fault, the section controller will record the fault and counter add one (it will be reset after a while if it have no subsequent failures). When the counter is more than the time you set, the section controller will trip. So that the fault zone can be cut off from the line.

Action Logic diagram:



IA IB IC—Measured current Iset—Pickup current T1—The time after count  
Cset—Count times which you set


#### 50 Instantaneous/Definite-Time Overcurrent (P.OC)

The controller adopts phase current through high precision 3 phase current sensor inside main body. The overcurrent faults could be judged according to phase current, if the current is greater than the set value, the controller will trip.

P.OC2/P.OC3 offer the time-overcurrent curve function.

Note: If the section function is run, the protection do not work.


Action Logic diagram:



IA IB IC—Measured current Iset—Pickup current T—Delay time

## Overload (Overload)

When the load of line is bigger than the rate value , overload protection will trip the circuit breaker



Note: Run is "√", Stop is "×".

IA IB IC—Measured current Iset—Pickup current T—Delay time


## 50N Residual Ground Instantaneous/Definite\_Time Overcurrent (G.OC)

The residual ground overcurrent elements are derived from phase current input channels IA, IB and IC. The residual Ground mode derives the earth current internally from the 3 phase CT inputs to give earth fault.

G.OC2/G.OC3 offer the time-overcurrent curve function.

Note: If the section function is run , the protection do not work.


Action Logic diagram :



Note: Run is "√", Stop is "×".

3IG—Earth current (3IN) 3IGset—Pickup current T—Delay time

Action Logic diagram with direction :



Note: Run is "√", Stop is "×".

3IG—Earth current (3IN) 3IGset—Pickup current T—Delay time

3IG<3U0—Angle of 3IN exceeding 3U0

Set start angle and end angle is in "Common value" menu



## 51SEF Sensitive earth fault (SEF)

The neutral ground over current element is derived from phase current input channel 3IN. Current channel 3IN is internally wired residually with phase current input channels IA, IB and IC, so the residual ground and neutral ground overcurrent elements see the same magnitude zero-sequence current.

Neutral Ground mode directly measures the earth current from an independent CT, this input can be ordered as sensitive earth fault.

Note: If the section function is run, the protection does not work.


Action Logic diagram:



Note: Run is "√", Stop is "×".

3IN—Sensitive earth current    3INset—Pickup current    T—Delay time

Action Logic diagram with direction:



Note: Run is "√", Stop is "×".

3IG—Sensitive earth current (3IN)    3IGset—Pickup current    T—Delay time

3IG<3U0—Angle of 3I0 exceeding 3U0


Set start angle and end angle is in "Common value" menu

The reference phase and phase range should be set when the protection is run in mode 1 (Direction mode). The reference phase and phase range must be set for judging ground faults on loading side and power supply side when it is installed in the middle of line.

The setting value means phase angle of zero sequence current when the phase angle of zero voltage is 0°. Normal setting method for different ground system as follows:

- Neutral ungrounded or small resistance ground system setting= $270^\circ \pm 85^\circ$ . In neutral ungrounded or small resistance ground system, the phase angle of zero sequence current and zero sequence voltage is close to  $270^\circ$  when ground fault happens on loading side. The phase angle of zero sequence current is close to  $70^\circ$  when ground fault happens on power supply side. So it's easy to distinguish ground fault on loading side or power supply side. According to above judgement basis, the most suitable phase setting range is  $270^\circ \pm 85^\circ$  in neutral ungrounded or small resistance ground system. The setting range could be regulated according to actual operation environment and condition.

- Arc-suppression coil ground system setting= $180^\circ \pm 85^\circ$ .  
In arc-suppression coil (NES) ground system, the range of phase angle for over compensation is  $> 90^\circ \sim < 180^\circ$  when the faults happen on loading side, however it is installed in the outlet terminal, or in the middle of line or in the end of line of substations, the range of phase angle for under compensation is  $> 180^\circ \sim < 270^\circ$ . The range of phase angle is  $> 0^\circ \sim < 90^\circ$  when the faults happen on power supply side. The most suitable phase angle setting range is  $180^\circ \pm 85^\circ$ . And also, the phase angle could be regulated according to actual operation environment and condition.




### 51c Cold Load Pickup (Cold load)

If a circuit breaker is closed onto a "cold" load, i.e. one that has not been powered for a prolonged period, this can impose a higher than normal load-current demand on the system which could exceed normal settings. These conditions can exist for an extended period and must not be interpreted as a fault. To allow optimum setting levels to be applied for normal operation, the cold load pickup feature will apply alternative current settings for a limited period. The feature resets when either the circuit breaker has been closed for a settable period, or if the current has reduced beneath a set level for a user set period.

When the time of the line lost current longer than the "Loss-load time", the load of the line be cold. Next time the line have current, "Cold load" protection start, the protection you set (phase fault/earth fault) is invalid, the recloser just trip when the current satisfy the logic diagram below. After the "Restore time", "Cold load" protection end and the protection you set is available.

Action Logic diagram:




Note: Run is "√", Stop is "×".

IA IB IC—Measure current      3I0—Measure Ground current (3IN)  
Iset—Pickup-Phase current      IGset—Pickup-Ground current

### TRSOTF Switch-Onto-Fault (SOTF)

When switching on manual closing acceleration, if accidents happened in the exit time after operated the close, the phase over current protection will accelerate the operation. The exit time of acceleration can be adjusted.

Action Logic diagram:




Note: Run is "√", Stop is "×".

IA IB IC—Measured current    Iset—Pickup current    T—Delay time  
T1— The time after manual close

### 59 Over Voltage (L.Over volt)

The device take the line voltage as the criterion for over voltage protection.

Action Logic diagram:



Note: Run is "√", Stop is "×".


UAB UBC UCA—Measured line voltage    Uset—Pickup voltage    T—Delay time

## 27 Under Voltage (L.Under volt)

The device take the line voltage as the criterion for under voltage protection. Under voltage protection include mode I (No voltage +Low voltage protection), mode II (Via current locking low voltage protection) and mode III (Pure low-voltage protection).

Action Logic diagram :

Mode 1: No voltage +Low voltage protection




Note: Run is "√", Stop is "×".

UAB UBC UCA—Measured line voltage Uset—Pickup voltage T—Delay time

U1—positive sequence voltage U2—negative sequence voltage

Mode2: Via current locking low voltage protection




Note: Run is "√", Stop is "×".

UAB UBC UCA—Measured line voltage Uset—Pickup voltage T—Delay time

IA IB IC—Measured current

### Mode3: Pure low-voltage protection




Note: Run is "√", Stop is "×".

UAB UBC UCA—Measured line voltage Uset—Pickup voltage T—Delay time  
U1—positive sequence voltage

## 81 Frequency Protection (Frequency)

When the frequency of the power PT is to high or to low, the Recloser will trip to protect the line.

Action Logic diagram :




Note: Run is "√", Stop is "×".

F—Frequency F/S—The rate of frequency (HZ) and seconds (S)  
UAB UBC UCA—Measured line voltage Uset—Pickup voltage T—Delay time

## Direct.Power

When the total three-phase power exceeds the set power, it will act after a delay time. This protection has directional options. When set to forward, if the active power exceeds the setting power value and is positive, it will trip; When set to reverse, if the active power exceeds the setting power value and is negative, it will trip.

Action Logic diagram :



Note: Run is "√", Stop is "×".

Total P—Three phase active power Pset—Pickup power T—Delay time

### **Control circuit breaking alarm**

In normal situation, the switch on and switch off signals are in different status, and when these two signals are in the same status for 10s, the device will send control circuit breaking alarming signal.

### **Hotline**

When the line is in the repair, you can turn on the feature of hotline, and we can not make any closing operation for safety. Press the "Hotline" pushbutton the feature of hotline is turned on. Press the "Hotline" pushbutton again, the feature of hotline is turned off.

### 3.2 Inverse time current protection

The following information describes the curve timing for the curve and time dial settings made for the time-overcurrent elements. The time-overcurrent relay curves conform to IEEE C37.112-1996 IEEE Standard Inverse-Time Characteristic Equations for Overcurrent Relays.

$T_p$  = Operating time in seconds

TD = Time-dial setting


M = Applied multiples of pickup current

#### Equations Associated With IEC Curves

No	Curve Type	Operating time
1	C1 (Standard Inverse)	$T_p = TD \bullet \left( \frac{0.14}{(M^{0.02} - 1)} \right)$
2	C2 (Very Inverse)	$T_p = TD \bullet \left( \frac{13.5}{(M - 1)} \right)$
3	C3 (Extremely Inverse)	$T_p = TD \bullet \left( \frac{80}{(M^2 - 1)} \right)$
4	C4 (Long-Time Inverse)	$T_p = TD \bullet \left( \frac{120}{(M - 1)} \right)$
5	C5 (Short-Time Inverse)	$T_p = TD \bullet \left( \frac{0.05}{(M^{0.04} - 1)} \right)$


#### Equations Associated With U.S.Curves

No	Curve Type	Operating time
6	U1 (Moderately Inverse)	$T_p = TD \bullet \left( 0.0226 + \frac{0.0104}{(M^{0.02} - 1)} \right)$
7	U2 (Inverse)	$T_p = TD \bullet \left( 0.180 + \frac{5.95}{(M^2 - 1)} \right)$
8	U3 (Very Inverse)	$T_p = TD \bullet \left( 0.0963 + \frac{3.88}{(M^2 - 1)} \right)$
9	U4 (Extremely Inverse)	$T_p = TD \bullet \left( 0.0352 + \frac{5.67}{(M^2 - 1)} \right)$
10	U5 (Short-Time Inverse)	$T_p = TD \bullet \left( 0.00262 + \frac{0.00342}{(M^{0.02} - 1)} \right)$




**IEC Class A Curve (Standard Inverse): C1**







**IEC Class B Curve (Very Inverse): C2**




**IEC Class C Curve (Extremely Inverse): C3**



**IEC Long-Time Inverse Curve: C4**




**IEC Short-Time Inverse Curve: C5**




**U.S. Moderately Inverse Curve: U1**






**U.S. Inverse Curve: U2**




**U.S. Very Inverse Curve: U3**




**U.S. Extremely Inverse Curve: U4**






**U.S. Short-Time Inverse Curve: U5**



RECLOSER CONTROL TIME OVERCURRENT CURVES

DWG. NO. T0C1005  
DATE: 25 JUN 88  
RECLOSER CURVE 1  
DECADE SCALE 2.215


Recloser Control Response Curves A, C, N, and W



RECLOSER CONTROL TIME OVERCURRENT CURVES

DWG. NO. TOC1006  
DATE: 25 JUN 88  
RECLOSER CURVE 2  
DECADE SCALE 2.213


Recloser Control Response Curves B, R, 2, and 3



RECLOSER CONTROL TIME OVERCURRENT CURVES


DWG. NO. 10C1007  
 DATE: 25 JUN 88  
 RECLOSER CURVE 3  
 DECADE SCALE 2.213

Recloser Control Response Curves D, 8PLUS, and 16



DWG. NO. TOC1008  
DATE: 25 JUN 98  
RECLOSER CURVE 4  
DECADE SCALE 2.213

Recloser Control Response Curves F, H, J, and 1




RECLOSER CONTROL TIME OVERCURRENT CURVES


DWG. NO. 10C1009  
DATE: 25 JUN 98  
RECLOSER CURVE 3  
DECADE SCALE 2.2:1

Recloser Control Response Curves G, V, 6, and 13






Recloser Control Response Curves E, P, and 18



DWG. NO. TOC1011  
 DATE: 25 JUN 88  
 RECLOSER CURVE 7  
 DECADE SCALE 2.213


Recloser Control Response Curves KG, Y, Z, and 5






DWG. NO. 10C1012  
 DATE: 25 JUN 88  
 RECLOSER CURVE 8  
 DECADE SCALE 3.213

Recloser Control Response Curves KP, M, T, and 17



Recloser Control Response Curves 4, 9, 11, and 14



DWG. NO. TOC1014  
 DATE: 25 JUN 88  
 RECLOSER CURVE 10  
 DECADE SCALE 2.213

**Recloser Control Response Curves L, 7, 8, and 15**

### 3.3 Constant Value Parameters

All values are given primary side.

#### Section

Description		Setting range	Step length
Section	Pickup current	1 ~ 6000A	1A
	Count	1 ~ 3	1
	Lock Reset time	1 ~ 180S	0.1S

#### 50/51 Phase Fault (P.OC/P.Fast curve/P.Delay curve)

Description		Setting range		Step length
P.OC1	Pickup current	1 ~ 6000A		1A
	Delay time	0 ~ 9.99S		0.01S
P.OC2	Curve type	0: NONE	1: IEC-SI	2: IEC-VI
		3: IEC-EI	4: IEC-LTI	5: IEC-STI
		6: U.S-MI	7: U.S-I	8: U.S-VI
		9: U.S-EI	10: U.S-STI	11: PB-80
		12: PTB-1	13: USER-1	14: USER-2
		13: USER-3	14: USER-4	
Pickup current	1 ~ 6000A		1A	
Time dial	0 ~ 99.99		0.01	
Time adder	0 ~ 99.99S		0.01S	
Minimum response	0 ~ 99.99S		0.01S	
P.OC3	Curve type	0: NONE	1: IEC-SI	2: IEC-VI
		3: IEC-EI	4: IEC-LTI	5: IEC-STI
		6: U.S-MI	7: U.S-I	8: U.S-VI
		9: U.S-EI	10: U.S-STI	11: PB-80
		12: PTB-1	13: USER-1	14: USER-2
		13: USER-3	14: USER-4	
Pickup current	1 ~ 6000A		1A	
Time dial	0 ~ 99.99		0.01	
Time adder	0 ~ 99.99S		0.01S	
Minimum response	0 ~ 99.99S		0.01S	

#### Overload (Overload)

Description		Setting range	Step length
Overload	Pickup current	1 ~ 6000A	1A
	Delay time	0 ~ 99.99S	0.01S

**50G/51G /Sensitive Earth Fault (G.OC/SEF)**

Description		Setting range	Step length
G.OC1	Direction mode	0: Disable 1: Enable	
	Pickup current	1 ~ 6000A	1A
	Delay time	0 ~ 9.99S	0.01S
G.OC2	Direction mode	0: Disable 1: Enable	
	Curve type	0: NONE      1: IEC-SI      2: IEC-VI 3: IEC-EI    4: IEC-LTI    5: IEC-STI 6: U.S-MI    7: U.S-I      8: U.S-VI 9: U.S-EI    10: U.S-STI   11: PB-80 12: PTB-1   13: USER-1   14: USER-2 13: USER-3   14: USER-4	
	Pickup current	1 ~ 6000A	1A
	Time dial	0 ~ 99.99	0.01
	Time adder	0 ~ 99.99S	0.01S
	Minimum response	0 ~ 99.99S	0.01S
G.OC3	Direction mode	0: Disable 1: Enable	
	Curve type	0: NONE      1: IEC-SI      2: IEC-VI 3: IEC-EI    4: IEC-LTI    5: IEC-STI 6: U.S-MI    7: U.S-I      8: U.S-VI 9: U.S-EI    10: U.S-STI   11: PB-80 12: PTB-1   13: USER-1   14: USER-2 13: USER-3   14: USER-4	
	Pickup current	1 ~ 6000A	1A
	Time dial	0 ~ 99.99	0.01
	Time adder	0 ~ 99.99S	0.01S
	Minimum response	0 ~ 99.99S	0.01S
SEF	Direction mode	0: Disable 1: Enable	
	Pickup current	1 ~ 80A	1A
	Delay time	0 ~ 9.99S	0.01S

**51c Cold Load Pickup (Cold load)**

Description		Setting range	Step length
Cold load	Pickup-Phase	1 ~ 6000A	1A
	Pickup-Ground	1 ~ 6000A	1A
	Loss-load time	0.1 ~ 99.99S	0.01S
	Restore time	0.1 ~ 99.99S	0.01S

**TRSOTF Switch-Onto-Fault (SOTF)**

Description		Setting range	Step length
SOTF	Exit time	0.1 ~ 9.99S	0.01S
	Pickup current	1 ~ 6000A	1A
	Delay time	0 ~ 9.99S	0.01S

**59 Over Voltage (L.Over volt)**

Description		Setting range	Step length
L.Over volt	Operating mode	0: Disable 1: Trip 2: Alarm	
	Pickup voltage	1~42KV	0.1KV
	Delay time	0 ~ 99.99S	0.01S
L.Over volt2	Operating mode	0: Disable 1: Trip 2: Alarm	
	Pickup voltage	1~42KV	0.1KV
	Delay time	0 ~ 99.99S	0.01S

**27 Under Voltage (L.Under volt)**

Description		Setting range	Step length
L.Under volt	Operating mode	0: Invalid 1: No voltage +Low voltage protection 2: Via current locking low voltage protection 3: Pure low-voltage protection	
	Pickup voltage	1~42KV	0.1KV
	Delay time	0 ~ 99.99S	0.01S
L.Under volt2	Operating mode	0: Invalid 1: No voltage +Low voltage protection 2: Via current locking low voltage protection 3: Pure low-voltage protection	
	Pickup voltage	1~42KV	0.1KV
	Delay time	0 ~ 99.99S	0.01S

**81 Frequency Protection (Frequency)**

Description		Setting range	Step length
Frequency	Low frequency	40 ~ 60Hz	0.1Hz
	High frequency	50 ~ 65Hz	0.1Hz
	Delay time	0.1 ~ 20S	0.01S
	Slip lock	0: Disable 1: Enable	
	Slip value	0.3 ~ 40	0.1
	Low volt. lock	0: Disable 1: Enable	
	Low volt. value	1 ~ 42KV	0.1KV

**Direct.Power**

Description		Setting range	Step length
Direct.Power	Operating mode	1: Trip 2: Alarm	
	Pickup power	1 ~ 60000KW	1KW
	Delay time	0 ~ 60000S	1S
	Direction mode	1-None 2-Forward 3-Reverse	

**Common value**

Description		Setting range	Step length
Common value	I Start angle	0 ~ 360	1
	I End angle	0 ~ 360	1
	I0 Start angle	0 ~ 360	1
	I0 End angle	0 ~ 360	1
	PT offline	0 ~ 2	1
	Under Volt.	1~42KV	0.1KV
	U2 lockout	1~42KV	0.1KV
	Lockout current	1 ~ 6000A	1A

### 3.4 Data Storage

Data records are backed up in non-volatile memory and are permanently stored even in the event of loss of auxiliary supply voltage. Data storage includes functions of trip count, wear and event records. These records can be reset clear.

#### Counters

Total Trip Count (ALL): Increments on each trip command issued.

Phase Overcurrent Trip Count (OC): Increments on phase overcurrent trip command issued.

Earth Fault Trip Count (EF): Increments on earth fault trip command issued.

Sensitive Earth Fault Trip Count (SEF): Increments on sensitive earth fault trip command issued.

Section Trip Count (SEC): Increments on section trip command issued.

Phase Overvoltage Trip Count (OV): Increments on phase overvoltage trip command issued.

Phase Under Voltage Trip Count (UV): Increments on phase under voltage trip command issued.

Voltage Unbalance Trip Count (VU): Increments on voltage unbalance trip command issued.

Electric Trip Count (Elec.): Increments on electric trip command issued.

Manual Trip Count (Manu.): Increments on manual trip command issued.

Remote Trip Count (Remote): Increments on remote trip command issued.

Other Trip Count (Oth): Increments on other trip command issued.

#### Wear

An I2t counter is also included and this can provide an estimation of contact wear and maintenance requirements. The algorithm works on a per phase basis, measuring the arcing current during faults. The I2t value at the time of trip is added to the previously stored value. The t value is the time between circuit breaker contacts separation when an arc is formed. Mechanical wear is the total number of trips divided by **CO Limit**.


#### Event Records

Event records include tripping records, alarm records and SOE records. The event recorder feature allows the time tagging of any change of state (Event) in the relay. As an event occurs, the actual event condition is logged as a record along with a time and date stamp to a resolution of 1ms. There is capacity for a maximum of 6400 event records (3000 trip records, 400 alarm records and 3000 SOE records) that can be stored in the relay and when the event buffer is full any new record will over-write the oldest. The following events are logged:

- Change of state of Binary outputs
- Change of state of Binary inputs
- Protection element operation




## Chapter 4: User Interface




The operator interface is designed to provide a user friendly method of controlling, viewing menus, entering settings and retrieving data from the relay. Eight buttons are provided for navigation around the menu structure.






## 4.1 Status and Trip Target LEDs






Most of the status and Trip Target LEDs and Operator Controls can change function (if desired by the user) by programming at a higher logic level. This subsection discusses each function as shipped from the factory and inscribed on the front panel.



## 4.2 Pushbuttons













Button	Function
	Illuminate all front-panel LEDs for 1 second.
	Clear trip-latched targets TRIP, FAST CURVE, HIGH CURRENT, 81, A, B, C, G, and SEF.
	Select displayed option or setting.
	Cancel command edit or escape to upper command level.
	Scroll up on display.

	Scroll down on display.
	Scroll left on display.
	Scroll right on display.
	increment value.
	decrement value.

### 4.3 Operator Controls

All the following operator control pushbuttons should be pressed momentarily to execute their function.

Press the <b>PROTECTION ENABLED</b> to enable/disable the protection tripping. Corresponding LED illuminates to indicate the enabled state.	
Press the <b>OVR ENABLED</b> to enable/disable the over-voltage element tripping. Corresponding LED illuminates to indicate the enabled state.	
Press the <b>UVR ENABLED</b> to enable/disable the under-voltage element tripping. Corresponding LED illuminates to indicate the enabled state.	
Press the <b>GROUND ENABLED</b> to enable/disable the ground over-current and sensitive earth fault (SEF) element tripping. Corresponding LED illuminates to indicate the enabled state.	

<p>Press the <b>REMOTE ENABLED</b> to enable/disable remote control. Corresponding LED illuminates to indicate the enabled state.</p>	
<p>Press the <b>HOTLINE ENABLED</b> to enable/disable hotline. Corresponding LED illuminates to indicate the enabled state. <b>NOTE:</b> When the reclose is in a status of hotline, the <b>CONTROLLER CLOSE</b> pushbutton is invalid.</p> <p>(Enter password to ON/OFF Lock button)</p>	
<p>Press the <b>LOCK</b> operator control pushbutton to enable/disable the lock function. Corresponding LED illuminates to indicate the reclose is locked. While the lock function is engaged, the following operator controls are "locked in position":</p> <p><b>PROTECTION ENABLED</b>    <b>HOTLINE</b>  <b>OVR ENABLED</b>            <b>BATTERY TEST</b>  <b>UVR ENABLED</b>            <b>CONTROLLER CLOSE</b>  <b>GROUND ENABLED</b>        <b>CONTROLLER OPEN</b>  <b>REMOTE ENABLED</b></p> <p>While "locked in position," these operator controls cannot change state if pressed—their corresponding LEDs remain in the same state. When the lock function is engaged, the CLOSE operator control can not close the break, but the TRIP operator control can still trip the break.</p> <p>(Enter password to ON/OFF Lock button)</p>	
<p>Press the <b>CLOSE</b> operator control pushbutton to show the voltage of battery about 10s.</p>	
<p>Press the <b>CLOSE</b> operator control pushbutton to close the controller. Corresponding <b>CONTROLLER CLOSED</b> LED illuminates to indicate the breaker is closed. The CLOSE operator control pushbutton does not have to be continually pressed to allow for cold load pickup (i.e., disable fast curves, and desensitize delay curves and SEF element). There is automatic allowance for cold load pickup. See the Cold Load Pickup settings in Chapter 3.1: Function Description.</p>	
<p>Press the <b>Open</b> operator control pushbutton to trip the breaker (and take the control to the lockout state). Corresponding <b>CONTROLLER OPEN</b> LED illuminates to indicate the reclose is Open.</p>	

#### 4.4 Default Display


The LCD default display shows IA, IB, IC, 3IN, Upt, UA, UB, UC, UR, US, UT, UAB.

**Note:** The light of the LCD will turn off after five minutes, if you do not operator the reclosing.



#### 4.5 The Main Menu














Press "Enter" when on the main screen, as shown below, including "EDIT" and "VIEW" menu item. Select the corresponding menu item with the [←] key, [→] and press "ENTER" button to enter the corresponding sub-menu, press the "ESC" key to return to the previous screen.







## 4.6 Submenu

### Edit submenu






Choose the edit options, the screen will enter the submenu of the Edit menu, as shown below, the submenu includes "Relay", "Para", "Port", "Chnl", "Clr", "Time", "Fac".

 Relay	 Chnl	 AGT
 Para	 Clr.	 Time
 Port	 Fac.	
<b>Submenu of edit</b>		
 Relay  	Enter "Relay" submenu, you can select the corresponding group to enter and view each protection feature and set up the parameters.	
 Para	Enter "Para" submenu, you can modify or view other parameters. Like CT rate, PT rate, PTS rate, Operator password, CO limit, Wear Limit-MA <sup>2</sup> s, Wear Clearance, Telesignal time, Close pulse time, Trip pulse time.	
 Port	Enter "Port" submenu, you can modify or view communication parameters.	
 Chnl	Enter "Chnl" submenu, current and voltage values can be corrected, press the function key "ENTER" to be modified.	







	Enter "Clr" submenu, you can clear out the events, counters, wear.
	Enter the "Time" submenu will modify or check the time.
	Automatic switchover can be set in the group, which can be switched to summer workday group, summer rest day group, winter workday group and winter rest day group. You can also set the start and end time of summer and the start and end time of rest days.
	Enter "Fac." Sub-menu, modify and view the factory settings.

### View submenu

Choose the view options, the screen will enter the submenu of the View menu, as shown below, the sub-menu includes "Pmete", "Smete", "RPT", "Relay", "Para", "Input", "Ver".


		
<b>View submenu</b>		
	Enter "PMete" submenu, you can view the primary side measurement data include: phase current, Ground current, PT voltage, phase voltage, line voltage, active power, reactive power, power factor, frequency, battery voltage, earth current with 3RD harmonics.	
	Enter "SMete" submenu, you can view the secondary side of the measured data include: phase current, Ground current, PT voltage, phase voltage, line voltage, negative-sequence current, negative sequence voltage, positive sequence voltage, zero-sequence voltage.	



	<p>Enter "RPT" submenu, you can view the trip report, alarm report, signal report, counters, wear.</p>
 	<p>Enter "Relay" submenu, you can select the corresponding group to enter and view each protection feature is invested and set up the parameters.</p>
	<p>Enter "Para" submenu, you can view his argument. Like CT rate, PT rate, PTS rate, Operator password, CO limit, Wear Limit-MA<sup>2</sup>s, Wear Clearance, Telesignal time, Close pulse time, Trip pulse time.</p>
	<p>Enter the "Input" submenu, you can view the input signal. The input signal includes: Breaker open, Breaker close, Remote open, Remote close, Low pressure, Manual lock, Door, Active battery, Power fault, Spring ready, 2st backup input.</p>
	<p>Enter "Ver" submenu, you can view the device type, version, date of manufacture and device ID.</p>

#### 4.7 Entering the password interface


According to the above operation, before entering each item will first enter a password input interface to prevent professional staff misuse. The device original password is "0099", as shown below, press [←] and [→] keys to switch, press the [+] and [-] keys to increase and decrease the number of line with the correct password press "Enter" button to enter.

	<p>Password interface</p>
---	---------------------------




## 4.8 Relay setting

Select the "Relay" in the Edit submenu item, press the function key "Enter" to enter the password screen, enter the correct password to enter the "Relay" submenu, as Shown below, each item has a checkbox and set values.

	<ol style="list-style-type: none"> <li>1、 Section: Section function</li> <li>2、 P.OC1: Instantaneous overcurrent</li> <li>3、 P.OC2: Time-Overcurrent fast Curves</li> <li>4、 P.OC3: Time-Overcurrent delay Curves</li> <li>5、 Overload: Overload function</li> <li>6、 G.OC1: Instantaneous Ground overcurrent</li> <li>7、 G.OC2: Gound Time-Overcurrent fast Curves</li> <li>8、 G.OC3: Ground Time-Overcurrent delay Curves</li> <li>9、 SEF: Sensitive earth fault protection</li> <li>10、 Cold load: Cold Load pickup</li> <li>11、 SOTF: Switch-Onto-Fault protection</li> <li>12、 L.Over volt: Over Voltage protection, 1<sup>st</sup></li> <li>13、 L.Over volt2: Over Voltage protection, 2<sup>nd</sup></li> <li>14、 L.Under volt: Under Voltage protection, 1<sup>st</sup></li> <li>15、 L.Under volt2: Under Voltage protection, 2<sup>nd</sup></li> <li>16、 Frequency: Frequency protection</li> <li>17、 Direct.Power: Direct power protection</li> <li>18、 Common value: PT supervision and some common values</li> </ol>
--	--


### Section (section)

Select **section** in relay menu press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Setting the section protection current value, the current value can be between 1A ~ 6000A.</p> <p>Step 2: Setting the section protection count times, the value can be between 1~ 3.</p> <p>Step 3: Setting the reset time, the time can be between 1.2S ~ 180S.</p> <p>Note: Press [ ↓ ] key to switch to next screen, press the [+] and [-] keys to modify the corresponding value.</p>
The operational processes of section function setting	


### Phase overcurrent (P.OC1)

Select **P.OC1** in relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Setting the overcurrent protection current value, the current value can be between 1A ~ 6000A.</p> <p>Step 2: Setting the overcurrent delay time, the delay time can be between 0S ~ 9.99S.</p> <p>Note: Press [ ↓ ] key to switch to next screen, press the [+] and [-] keys to modify the corresponding value.</p>
<p>The operational processes of simple overcurrent protection setting</p>	

### Phase fault fast curve protection (P.OC2)

Select **P.OC2** in relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the Curve type of Inverse-time overcurrent or definite time overcurrent (NONE).</p> <p>Step 2: Setting the overcurrent protection current value, the current value can be between 1A ~ 6000A.</p> <p>Step 3: Setting the Time dial of time-overcurrent curve.</p> <p>Step 4: Setting the Time adder of time-overcurrent curve (the delay time to trip after "Tp").</p> <p>Step 5: Setting the Minimum response of time-overcurrent curve (If the "Tp" less than it, the recloser will trip after this time).</p> <p>Note: Press [ ↓ ] key to switch to next screen, press the [+] and [-] keys to modify the corresponding value.</p>
<p>The operational processes of phase fast curve protection setting</p>	

### Phase fault delay curve protection (P.OC3)

Select **P.OC3** in relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the Curve type of Inverse-time overcurrent or definite time overcurrent (NONE).</p>
	<p>Step 2: Setting the overcurrent protection current value, the current value can be between 1A ~ 6000A.</p>
	<p>Step 3: Setting the Time dial of time-overcurrent curve.</p>
	<p>Step 4: Setting the Time adder of time-overcurrent curve (the delay time to trip after "Tp").</p>
	<p>Step 5: Setting the Minimum response of time-overcurrent curve (If the "Tp" less than it, the recloser will trip after this time).</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>	
<p>The operational processes of phase delay curve protection setting</p>	

### Overload (Overload)

Select **Overload** in relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Setting the overload protection current value, the current value can be between 1A ~ 6000A.</p>
	<p>Step 2: Setting the overload delay time, the delay time can be between 0S ~ 99.99S.</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>	
<p>The operational processes of overload protection setting</p>	

## Earth Fault (G.OC1)

Select **G.OC1** in the relay menu press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the direction mode (0: No-direction earth fault, 1: Directional earth fault).</p> <p>Step 2: Setting the earth fault protection current value, the current value can be between 1A ~ 6000A.</p> <p>Step 3: Setting the earth fault delay time, the delay time can be between 0S ~ 9.99S.</p> <p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>
<p>The operational processes of G.OC1 protection setting</p>	

## Ground fast curve protection (G.OC2)

Select **G.OC2** in relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the operating mode (0: No-direction earth fault, 1: Directional earth fault).</p> <p>Step 2: Choose the Curve type of Inverse-time earth overcurrent or definite time overcurrent (NONE).</p> <p>Step 3: Setting the earth overcurrent protection current value, the current value can be between 1A ~ 6000A.</p> <p>Step 4: Setting the Time dial of time-overcurrent curve.</p> <p>Step 5: Setting the Time adder of time-overcurrent curve (the delay time to trip after "Tp").</p> <p>Step 6: Setting the Minimum response of time-overcurrent curve (If the "Tp" less than it, the recloser will trip after this time).</p> <p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>
<p>The operational processes of ground fast curve protection setting</p>	

## Ground delay curve protection (G.OC3)

Select **G.OC3** in relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the operating mode (0: No-direction earth fault, 1: Directional earth fault).</p>
	<p>Step 2: Choose the Curve type of Inverse-time earth overcurrent or definite time overcurrent (NONE).</p>
	<p>Step 3: Setting the earth overcurrent protection current value, the current value can be between 1A ~ 6000A.</p>
	<p>Step 4: Setting the Time dial of time-overcurrent curve.</p>
	<p>Step 5: Setting the Time adder of time-overcurrent curve (the delay time to trip after "Tp").</p>
	<p>Step 6: Setting the Minimum response of time-overcurrent curve (If the "Tp" less than it, the recloser will trip after this time).</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>	
<p>The operational processes of ground delay curve protection setting</p>	





## Sensitive earth fault

Select **SEF** in the relay menu press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the operating mode (0: No-direction earth fault, 1: Directional earth fault).</p>
	<p>Step 2: Setting the sensitive earth fault protection current value, the current value can be between 1A ~ 80A.</p>
	<p>Step 3: Setting the sensitive earth fault delay time, the delay time can be between 0S ~ 9.99S.</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>	
<p>The operational processes of SEF protection setting</p>	




## Cold Load (ColdLoad)

Select ColdLoad in the relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Setting the cold load protection phase current value, the current value can be between 1A ~ 6000A.</p>
	<p>Step 2: Setting the cold load protection ground current value, the current value can be between 1A ~ 6000A.</p>
	<p>Step 3: Setting the loss-load time, the time can be between 0.1S ~ 99.99S.</p>
	<p>Step 4: Setting the restore time, the time can be between 0.1S ~ 99.99S.</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>	
<p>The operational processes of cold load protection setting</p>	


## Switch-Onto-Fault (SOTF)

Select SOTF in the relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Setting the SOTF exit time, the exit time can be between 0.1S~9.99S.</p>
	<p>Step 2: Setting the SOTF protection current value, the current value can be between 1A ~ 6000A.</p>
	<p>Step 3: Setting the delay time, the delay time can be between 0S ~ 9.99S.</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>	
<p>The operational processes of manual closing acceleration protection setting</p>	

## Low-voltage protection (L.Under volt)


Select **L.Under volt** in the relay menu press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the operating mode (0: Invalid, 1: No voltage + low voltage protection, 2: Via current lock low-voltage protection, 3: Pure low voltage protection).</p> <p>Step 2: Setting the protection voltage value, the voltage value can be between 1KV ~ 42KV.</p> <p>Step 3: Setting the delay time, the delay time can be between 0S ~ 99.99S.</p> <p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>
The operational processes of Under voltage protection setting	

Note: This is L.Under volt protection setting, the use of the L.Under volt2 protection is the same. The lockout current is in the common value.

## Over Voltage (L.Over volt)

Select **L.Over volt** in the relay menu, press "Enter" key to enter, operational processes as shown below:








	<p>Step 1: Choose the operating mode (0: Disable, 1: Trip, 2: Alarm).</p> <p>Step 2: Setting the protection voltage value, the voltage value can be between 1KV ~ 42KV.</p> <p>Step 3: Setting the delay time, the delay time can be between 0S ~ 99.99S.</p> <p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modify the corresponding value.</p>
The operational processes of over voltage protection setting	

Note: This is L.Over volt protection setting, the use of the L.Over volt2 protection is the same.







## Frequency protection (Frequency)

Select **Frequency** in the relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Set the low frequency, the low frequency can be between 40Hz~60Hz.</p>
	<p>Step 2: Set the high frequency, the high frequency can be between 50Hz~65Hz.</p>
	<p>Step 3: Set the delay time, the delay time can be between 0.1S ~ 20S.</p>
	<p>Step 4: Set the slip lock, the slip lock can be between 0 ~1 (0: disable 1: enable).</p>
	<p>Step 5: Set the slip value, the slip value can be between 0.3 ~40.</p>
	<p>Step 6: Set the low Voltage lock value, low Voltage lock value can be between 0 ~1 (0: disable 1: enable).</p>
	<p>Step 7: Set the low Voltage value, low Voltage value can be between 1KV~42KV.</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to modified value.</p>	
<p>The operational processes of frequency protection setting</p>	

## Direct.Power

Select **Direct.Power** in the relay menu, press "Enter" key to enter, operational processes as shown below:

	<p>Step 1: Choose the operating mode (1: Trip, 2: Alarm).</p>
	<p>Step 2: Set the protection power value, the power value can be between 1KW ~ 60000KW.</p>
	<p>Step 3: Set the delay time, the delay time can be between 0S ~ 60000S.</p>
	<p>Step 4: Set the direction mode. None: overpower without direction; Forward: forward direction overpower; Reverse: reverse direction overpower.</p>
<p>Note: Press [ ↓ ] key to switch to next screen, press the [ + ] and [ - ] keys to switch the mode, modified current value and delayed time.</p>	
<p>The operational processes of direct power protection setting</p>	



## PT breaking alarm (Common value)

Select **Common value** in the relay menu, press "Enter" key to enter, operational processes as shown below:

Common value 5/7  
PT offline  
0  
Scp:0 -2

Step 1: Choose the PT offline mode (0: Stop, 1: Lockout voltage related components, 2: Unlock voltage related components), press the [+] and [-] keys to switch the mode.

Common value 6/7  
Under Volt.  
05.0 KV  
Scp:01.0 -42.0

Step 2: Setting the under voltage value, the under voltage value can be between 1KV ~ 42KV.

Common value 7/7  
U2 lockout  
05.0 KV  
Scp:01.0 -42.0

Step 3: Setting the "U2 Lockout" value, the "U2 Lockout" value can be between 1KV ~ 42KV.

Note: Press [↓] key to switch to next screen, press the [+] and [-] keys to modify the corresponding value.

The operational processes of PT breaking alarming setting

## Other common values (Common value)

Select **Common value** in the relay menu, press "Enter" key to enter, as shown below:

Common value 1/7  
I Start angle  
330  
Scp:000 -360

Common value 2/7  
I End angle  
090  
Scp:000 -360

The angle for judging the direction is set here. I0 start angle and I0 end angle are used for ground current.





Common value 3/7  
I0 Start angle  
240  
Scp:000 -360

Note: Press [↓] key to switch to next screen, press the [+] and [-] keys to modify the corresponding value.

Common value 4/7  
I0 End angle  
300  
Scp:000 -360

The common value




## 4.9 Save parameter

	After setting, press "ESC" key to exit, if modified below figure will show. If you need to save press "Enter" key and input password, otherwise press "ESC" key.
	If you want to save, press the "Enter" key, and you need to enter the correct password to save.
	This interface appears, indicating that the saving is successful.
	If the password is error, this interface will appear.

## 4.10 Parameter set

Press the **EDIT** → **Para**, enter the "parameter set".


### CT, VS and PTS rate set

	<p>CT rate is the measurement of three phase current. The value of CT ratio is equal to the primary side current value divided by the secondary side current value.</p> <p>For e.g., <math>400/1 = 400</math> or <math>600/5 = 120</math>.</p>
	<p>VS ratio of the voltage sensor. The value of VS ratio is equal to the primary side resistance value divided by the secondary side resistance value.</p> <p>The default secondary side resistance value is 0.036MΩ.</p> <p>For e.g., 1. the primary side resistance value is 160MΩ, <math>160/0.036 = 4444</math>; 2. the primary side resistance value is 500MΩ, <math>500/0.036 = 13888</math>.</p>
	<p>PTS rate is the measurement of power Voltage. The value of PTS ratio is equal to the primary side Voltage value divided by the secondary side Voltage value.</p> <p>For e.g., <math>11000/110 = 100</math> or <math>24000/220 = 109</math>.</p>




Note:

- 1 Different current transformer, CT ratio becomes different.
- 2 Different Voltage sensor, VS ratio becomes different.
- 3 Different PT power Voltage transformer, PTS ratio becomes different.

## Password set



 <p>Parameter set Operate password 0099 Scp: 0000 -9999</p>	The device initial password is "0099", the password for the user to modify from the "0000" ~ "9999", when revised press "Enter" key to confirm, enter the password before the modification.
--	---

### Wear set

 <p>Parameter set CO Limit 010 K Scp: 001 -999</p>	The rated number of mechanical trips is divided by the total number of trips to obtain the mechanical wear ratio.
 <p>Parameter set Wear Limit-MA^2s 0180 Scp: 0001 -9999</p>	Target value of wear per phase.
 <p>Parameter set Wear Clearance 0.015 S Scp: 0.001 -0.200</p>	Arcing time of circuit breaker.

Note: Please do not modify these values, if in doubt, please contact supplier.



### Close and trip pulse time set

 <p>Parameter set Close pulse time 0040 ms Scp: 0010 -9999</p>	"Close pulse time" is the discharge time for close coil.
 <p>Parameter set Trip pulse time 0030 ms Scp: 0010 -9999</p>	"Trip pulse time" is the discharge time for trip coil.

Note: Please do not modify the trip and close pulse time, if in doubt, please contact supplier.

## 4.11 Communication

Press the **EDIT** → **Prot**, enter to the communication set menu.

	<p>There are 2 communication channels in total here. Enter the corresponding channels and set the corresponding settings. The channel settings are as follows. There is also a common setting.</p> <p>Note: Press [ ↓ ] key to choose the port which you need to set, press the [Enter] to Enter the menu, press [+] and [-] keys to modified communication value.</p>
	<p>Step 1: Enable this channel 0: Close this channel 1: Open this channel</p> <p>Step 2: Set the baud rate of this channel (Default 9600).</p> <p>Step 3: Select the communication protocol for this channel 1: IEC60870-5-101 2: IEC60870-5-104 3: DNP3.0 4: MODBUS</p> <p>Step 4: Choose whether IEC60870-5-101 protocol is balanced. 0: Unbalanced 1: Balance</p> <p>Step 5: Set up device address or source address.</p> <p>Step 6: Set up destination address (DNP3.0 needs to be set).</p> <p>Step 7: Enable active upload (For 101 and 104 protocols). 0: Do not upload actively 1: Active upload</p> <p>Step 8: Enable the active upload of signaling (For 101 and 104 protocols).</p> <p>Step 9: How often is the signal uploaded.</p> <p>Step 10: Enable the active upload of meter (For 101 and 104 protocols).</p> <p>Step 11: How often is the meter uploaded.</p> <p>Note: The settings of the three channels are the same.</p>

Communication common settings are as follows:

Name	Setting range	Step length	Description
Signal type	1 ~ 2	1	1: Single point 2: Double point
Control type	1 ~ 2	1	1: Single point 2: Double point
Meter type	1 ~ 4	1	1: Normalized telemetry 2: Normalized telemetry without quality 3: Standardized telemetry 4: Short floating point telemetry
Address len	1 ~ 2	1	Address length 1: 1 byte 2: 2 byte
COT len	1 ~ 2	1	COT length 1: 1 byte 2: 2 byte
I factor	0.01 ~ 100	0.01	Phase current multiplier
I deadband	0.1 ~ 1000	0.1	Phase current dead zone
IO factor	0.01 ~ 100	0.01	Zero sequence current multiplier
IO deadband	0.1 ~ 1000	0.1	Zero sequence current dead zone
U factor	0.01 ~ 100	0.01	Line voltage multiplier
U deadband	0.1 ~ 1000	0.1	Line voltage dead zone
U0 factor	0.01 ~ 100	0.01	Zero sequence voltage multiplier
U0 deadband	0.1 ~ 1000	0.1	Zero sequence voltage dead zone
P factor	0.01 ~ 100	0.01	Power multiplier
P deadband	1 ~ 10000	1	Power dead zone
COS factor	0.01 ~ 100	0.01	COS multiplier
COS deadband	0.01 ~ 1	0.01	COS dead zone
OTH factor	0.01 ~ 100	0.01	Other multiplier
OTH deadband	0.01 ~ 1	0.01	Other dead zone
CLASSA	0 ~ 3	1	Class for analog event data
CLASSB	0 ~ 3	1	Class for digital event data
Select Timeout	0 ~ 30	0.1	Select/operate time-out
Confirm Link	0 ~ 1	1	Enable confirm data link (For 101 and 104 protocols)
Link Retry Times	0 ~ 15	1	Data link retries times
Link Timeout	0 ~ 50	0.1	Seconds to data link time-out
Upload Confirm	0 ~ 1	1	Enable upload confirmation (For DNP3.0 protocols)
Upload Timeout	0 ~ 50	0.1	Seconds to upload time-out
Upload Retry Times	2 ~ 10	1	Upload retries times
Auto Refresh	0 ~ 1	1	Enable automatic reset of events
Refresh time	0 ~ 65535	1	Seconds to automatic reset event

## 4.12 Calibration

Select the **Edit** submenu in "Chnl", press "Enter" key to enter into the password screen, enter the correct password to enter the "Chnl" submenu, press the [+] and [-] keys to correct the value of current and voltage.

Note: All voltage and current values in the factory have been corrected before. Please do not change the parameter values which, if in doubt, please contact supplier.

## 4.13 Clear

Select the **Edit** submenu in "Clr.", press "Enter" key to enter the "Clr." Submenu. The stored data can be cleared here. The contents include event records, counters, wear.

Press "↑" and "↓" keys to switch, select the option to be cleared and press the "Enter" key to enter the correct password.

## 4.14 Auto switch group

Press the **EDIT** → **AGT**, enter to the auto switch group set menu. Automatic switchover can be set in this menu, which can be switched to summer workday group, summer rest day group, winter workday group and winter rest day group. You can also set the start and end time of summer and the start and end time of rest days. Automatic group switching is based on time.

## 4.15 View relay and setting

Enter the main menu select the "VIEW" option press "Enter" key to enter, and then select the "Relay" option to press "Enter" key to enter the "Relay" submenu, you can view all the protection is enabled or disabled, select protection option press "Enter" key to enter the value you can view each protection, press the arrow keys to switch screens.

Section	X
P.OC1	X
P.OC2	X
P.OC3	X
Over load	X
G.OC1	X
G.OC2	X
G.OC3	X
SEF	X
Cold load	X
SOTF	X
L.Over volt	X
L.Over volt2	X
L.Under volt	X
L.Under volt2	X
Frequency	X
Direct.Power	X
Common value	

#### **4.16 View report**

Enter the main menu select the "VIEW" option press "Enter" key to enter, and then select "RPT" option press "Enter" key to enter the "RPT" submenu, you can view the recording events include: trip signal, alarm signals, SOE signal (circuit breaker status, whether the manual or remote operation, fault trip, time and date, etc.), counters, wear.


#### **4.17 View input signal**

Enter the main menu select the "VIEW" option press "Enter" key to enter, and then select the "Input" option press "Enter" key to enter the "Input" submenu, you can view the state of input signal.

The input signal includes: Breaker open, Breaker close, Remote open, Remote close, Low pressure, Manual lock, Door, Active battery, Power fault, Spring ready, 2st backup input. 0 to 1 represents binary input.

## Chapter 5: Peripheral Accessories





### 5.1 RF remote controller

	<p>Function of each key</p> <p>A:Close</p> <p>B:Trip</p> <p>C:Unlock</p> <p>D:Reset</p>
---	---

Note:

1. In order to prevent misuse, press the unlock button for 3 seconds, before execution of the closing operation.
2. The effective distance of RF remote controller is 30 meters.

### 5.2 Features and the use of external sockets and switches



			
AC power switch	Backup switch	Socket	Activation button

Note: Before using the controller, ensure that the battery charge enough for 12 hours.

1. The AC power switch is for protecting the Auxiliary PT (Or utility incomer), and the BACKUP switch is for charging batteries.
2. After charging the batteries, turn off the power switch to protect the batteries for storage.
3. Activation button is not allowed for pressing last long time, or permanent damage of battery under-voltage may result.




### 5.3 The main secondary component parts

	
<p>Cable plug, connect the controller and circuit breakers</p>	<p>Surge protector</p>

Note: For security norms, Surge protector has to be grounded (green line) to the earth.

### 5.4 Capacitor (Used by permanent recloser)

	<ol style="list-style-type: none"> <li>1 Temperature range: <math>-25^{\circ}\text{C} \sim +105^{\circ}\text{C}</math>.</li> <li>2 Rated voltage: DC250V.</li> <li>3 Capacity: 33000Uf (<math>-20\% \sim +20\%</math>).</li> <li>4 Rated ripple current: 34.7Arms.</li> </ol>
--	---

Note: The following operation will cause self-heating of the capacitor that can result in leaking electrolyte outside the seal area. worst of all, perhaps there will be burst or spark that can lead the capacitor to spontaneous combustion.

1. Inverse voltage.
2. Overvoltage (over rated voltage).
3. Exceeding the rated ripple current.
4. Violently charge/discharge.

### 5.5 Battery

- RWK-351 stand-by battery adopts two 7AH lead-acid free of maintenance batteries, the average battery life exceeds 3 years.
- Please replace the storage battery in time when the storage battery exceeds its usage life. Replace method as following: firstly push the stand-by power supply switch to trip position, and pull out the connection cable simultaneously, rotate the support bolt away, replace the used battery with new battery. Then recover the device to the original status according to the contrary sequence. Please deal with the used battery properly in order not to pollute the environment.

## Chapter 6: Installation and Maintenance

**Danger:** The dangerous voltage with the device maybe result in the permanent damage of equipment or personnel casualty during installing RWK-381. These voltages mainly distributes at terminal bar of device and circuits of AC current input, AC voltage input, digital input, IGBT output and operation power supply., etc. This device's installation, debugging and maintenance can only be operated by technical staff who has been authorized and trained strictly.

### 6.1 Installation

☆ **See the Quick Reference Guide for details!**

### 6.2 Maintenance

- If the device is not used, it should be kept in dry and ventilated places indoors, and charged once every three months, the charging time should be more than 24 hours. Before the device is used, the charging time should not be less than 24 hours. Replace the storage battery each three years.
- This device has storage battery management module, which will automatically cut off the storage battery output circuit when the storage battery voltage is on the low side. You should check the storage battery each year, please replace the storage battery immediately when single storage battery voltage id lower than DC12V.
- Please firstly make sure the first system is power off before the device is maintained, forbid inserting or pulling out aeronautical connector under power, thus avoid CT short circuit happening.

### 6.3 Parts Attached with the Device

Name	Quantity	Collocation	Usage or Description
Box door key	1	Standard	Open the box
User Manual	1	Standard	Please read it carefully before use the device, controller wiring diagram is attached.
Hand-held telecontroller	1	Selectable	Telecontrol the close and trip of switch within 30 meters
CD	1	Standard	Testing debugging software
Communication Interface	1	Selectable	RS485/USB converter or RS485/RS232 converter
Control Cable	1	Standard	20 cords (6 meters)
Power Cable	1	Selectable	2 cords power cable (6 meters)

## Chapter 7: Decommission and Disposal

### 7.1 Decommission

#### Shut-down Power Supply

Shut-down Device Power Supply: Turn off external power supply switch of the device.

#### Disconnect All Power Cables

Disconnect all power cables connected to the device.

Danger: Before disconnecting all power cables connected to the device power module, it must confirm that the external power switch is turned off to avoid danger.

Danger: Disconnecting all power cables connected to the device alternating current module, it must confirm that the equipment corresponding to input alternating component has stopped operation to avoid danger.

#### Dismantle from Display Cabinet

When the above steps are completed, loosen the fix screws and dismantle the device from the display cabinet.

Danger: When neighboring equipment is in operation, it must strictly confirm the safety distance between the dismantled device and other device in operation and unskilled professional shall take particular caution.

### 7.2 Disposal

When dispose decommissioned device, please follow relevant regulations of the country where the product is used for the disposal of scrapped electronic products.

Caution: It must strictly adhere to relevant regulations of the country where the product is used for the disposal of scrapped electronic products.